




Ordered Intermetallics as Electrocatalysts for Fuel Cell Applications




Héctor D. Abruña, Francis J. DiSalvo
Dept. of Chemistry and Chemical Biology
Baker Laboratory, Cornell University
Ithaca, New York 14853-1301




Alloys vs. Ordered Intermetallics

Alloy; e.g. Pt/Ru (1:1)



(A)

Ordered Intermetallic
e.g. BiPt



(B)


Bismuth Platinum (BiPt) Intermetallic Phase

➤ Powder X-ray Diffraction Refinement for BiPt



$P6_3/mmc$

$a = 4.315 \text{ \AA}$


$c = 5.490 \text{ \AA}$



--- Residual between experimental and theoretical results




Platinum vs. PtBi



Pt

(111) plane

Pt-Pt 2.77 Å




PtBi





(001) plane

Pt-Pt 4.32 Å



Voltammetric Profile in H₂SO₄


- Cyclic Voltammetry in 0.1 M H₂SO₄ at a sweep rate of 10 mV/s




E(V) vs. Ag/AgCl

Enhanced Catalytic Activity for Formic Acid Oxidation



- Cyclic Voltammetry in 0.1 M H_2SO_4 + 0.125 M formic acid solution at a sweep rate of 10 mV/s




*Onset Potential (obtained at 10 mA/cm²)
as a function of the Formic Acid concentration.*




Rotating Disk Electrode Characterization




CO Tolerance




Cyclic voltammograms at 50 mV/sec for a BiPt electrode in 0.1M H₂SO₄ **before** and **after** exposure to CO






CO Adsorption on a polycrystalline Pt surface





Differential Electrochemical Mass Spectrometry
(DEMS)



DEMS for BiPt in
0.125 M HCOOH,
0.1 M H₂SO₄





FT-IR Studies of
CO₂ and CO
formation at BiPt
and Pt electrodes
during formic acid
oxidation.

Conclusions:

We have studied the electrocatalytic activity of the ordered intermetallic BiPt toward formic acid oxidation. This material exhibits enhanced electrocatalytic activity when compared to polycrystalline platinum. Using cyclic voltammetry, rotating disk electrode voltammetry (RDE), FTIR and DEMS (differential electrochemical mass spectrometry) we have characterized the current density, onset potentials, kinetics of oxidation, reaction intermediates, and product distribution.

Coworkers:

Emerilis Casado-Rivera

Zoltan Gal

Antonio Carlos Dias Angelo

Cora Lind

David Volpe

Laif Alden

Craig Downie

Support:

NSF, DOE