

Reformate Cleanup: The Case for Microchannel Architecture

**DOE Hydrogen and Fuel Cells
2003 Annual Merit Review**

May 19-22, 2003

W.E. TeGrotenhuis

K.P. Brooks, J.M. Davis, C.M. Fischer, D.L. King,
L.R. Pederson, G.C. Rawlings, V.S. Stenkamp,
R.S. Wegeng, G.A. Whyatt

Pacific Northwest National Laboratory

Overview

▶ Reformate Cleanup

- Water Gas Shift (WGS)
- Preferential Oxidation (PROX)
- Desulfurization

▶ Balance of Plant

- Water Management - Partial Condenser / Phase Separator

Objectives and Relevance

► Overall Objective

- Apply microchannel architectures where appropriate in fuel processing for transportation, stationary, and portable applications to reduce size and weight, improve fuel efficiency, and enhance operation.

► Technical Challenges – Approaches


- Compact size and weight to meet packaging requirements – rapid heat and mass transfer for high hardware productivity
- Thermal management – high heat transfer effectiveness in heat exchangers and reactors for maximum heat utilization and high fuel efficiency
- Water management – compact and efficient air-cooled partial condensers
- Rapid start-up – imbedded heat transfer in reactors facilitates rapid heating
- Cost – improved productivity of precious metal catalysts

Project Timeline



FY 1998

Full-size gasoline
vaporizer/combustor
R&D100 Award



FY 1999

Fast SR kinetics
observed in a
microchannel reactor





FY 2000

10 kWe SR system
Invented phase separator
concept



FY2001

10 kWe reactor testing
First "low dP" vaporizers
Demonstrated partial condenser



FY 2002

WGS/PROX catalyst studies
Differential temperature reactor concept
SR/WGS/PROX initial integration
Air-cooled partial condenser


Engineered catalyst,
reactor
development

Demonstrate rapid
start capability

Sulfur management


Integrated reformer/fuel cell
demonstration at ~2 kWe

Collaborate with industrial partner(s) on
manufacturing, field testing, lifetime, controls



FY 2003

2 kWe WGS and PROX
reactors.
Improve SR kinetics and
sulfur tolerance.



Differential Temperature Water Gas Shift Reactor

Objective/Approach

► Objective:


- 90% Conversion single-stage WGS reactor < 3 liters at full-scale

► Approach:



- Precious metal catalyst for high activity
- Integrate microchannel heat exchange for temperature control
- Optimize thermal profile
- Reduce catalyst loading by up to 1/2

► Relevance


- Smaller size – higher power density and specific power
- Reduced cost
 - Improved catalyst efficiency
 - 3 devices collapsed into 1
- Potential of higher energy efficiency



Conventional 2-stage Adiabatic



Ideal profile



Differential Temperature Water-Gas Shift

Progress: Multi-channel Reactor Testing

Prototype 7-channel Reactor



Reactor can be operated isothermally or with a temperature gradient

PROGRESS:


- Catalytic activity improved in multi-channel prototype reactor
- Up to 79% CO conversion (12.4% to 2.6% dry CO) in single stage at 100,000 GHSV and 0.65 steam:gas.

ISSUES:

- Activity diminishes at lower GHSV
- Loss of temperature dependence


Activity coefficients from isothermal reactor FEA model:

$$r_{CO} = \rho_B k_{CO}(T) p_{CO}^{-1} p_{H_2}^{-1} p_{CO_2}^{-1/2} \left(p_{H_2O} p_{CO} - \frac{p_{H_2} p_{CO_2}}{K_{eq}(T)} \right)$$



Differential Temperature Water-Gas Shift

Progress: Differential Mode Testing



► Conditions

- Steam Reformate Feed
 - 12.4% dry CO
 - 14.3% dry CO₂
 - 0.65 Steam:Gas
- 100K GHSV
- Isothermal operation at high heat exchange flow
- Differential temperature operation
 - Feed at 350C
 - 2 SLPM air coolant fed at outlet temperature

- ♦ Isothermal Operation - Outlet Gas CO%
- ◻ Differential Temperature Operation - Outlet Gas CO%
- Isothermal Operation - CO Conversion
- ◻ Differential Temperature - CO Conversion
- Equilibrium Conversion

Differential Temperature Water-Gas Shift


Issue: Flow Maldistribution

► Flow maldistribution between channels is an important issue

- Flow rate $\propto d_h^3$
- Compounded by increased heat and mass transfer resistance

► Example

- Impact of 20% distribution in hydraulic diameter on optimal conversion profile
- Does not account for heat and mass transfer effects
- Does not account for catalyst loading maldistribution



Differential Temperature Water-Gas Shift

Future Plans

- ▶ Continue catalyst development
 - Long-term testing
 - Start-up/shutdown and temperature cycling
 - Evaluate new formulations
 - Improved activity
 - Better activity maintenance
 - Sulfur sensitivity
 - Optimization of geometry and loading
- ▶ Multi-channel Improvements
 - Apply improved design and fabrication techniques to improve channel consistency
 - Demonstrate >90% conversion in single stage with integral heat exchange
- ▶ Develop WGS Reactor at 2 kWe-scale
 - Optimize catalyst productivity
 - Thermally integrate with 2 kWe-scale reformer system

Microchannel PROX Reactor Investigations


- ▶ Objective: Determine whether microchannel architecture provides opportunities for size, weight reduction for PROX reactor.
- ▶ Approach:
 - Single-channel catalyst tests – evaluate industrial PROX catalysts for fast kinetics
 - Design & test 2 kWe PROX reactor unit; confirm favorable operational characteristics
 - Investigate weight reductions through use of low-density alloys (e.g., alloys of aluminum and titanium)
 - Investigate transient and startup characteristics
- ▶ Progress:
 - 1st Stage PROX microchannel reactor demonstrated at 2 kWe scale – exhibits high productivity due to internal microchannel heat exchangers providing temperature control

Preliminary Single Channel Catalyst Tests Used to Down-select for 2kW PROX Unit

- ▶ At 1% CO in reformat, both precious metal and non-precious metal catalysts can be employed for PROX
 - Both catalysts show maximum CO conversion around 200°C
 - Adiabatic operation must be avoided (excessive temperature rise)
- ▶ At 0.1% CO in reformat, precious metal catalyst are required
 - Higher CO activity at lower temperatures (~100°C)
 - Lower activation energy
 - Different dependence on CO concentration (analogous to wgs)
 - Adiabatic operation may be possible
- ▶ Non-precious metal catalyst was selected for 2kW PROX test in microchannel hardware
 - CO ~1%, input from wgs reactor
 - Lower catalyst cost
 - Higher CO oxidation selectivity (lower H₂ consumption and O₂ requirements)


Selective CO Oxidation (PROX) With Non-Precious Metal Catalyst

Wet GHSV = 100,000, S/G = 0.3, O₂/CO = 1.0





Demonstration of Microchannel PROX Unit

- ▶ Designed as 1st Stage PROX for 2 kWe operation
- ▶ Operates as a quasi-isothermal reactor
 - Incorporates microchannel heat exchange
- ▶ Employs non-precious metal catalyst
- ▶ Allow multi-compartment bleed-in of air



Operation of First Stage Microchannel PROX



Future PROX Work

- ▶ Continue to evaluate industrial PROX catalysts for use in microchannel reactors
- ▶ Evaluate aluminum and titanium alloys for microchannel PROX reactor
 - Potential weight reduction
- ▶ Integration of 1st and 2nd Stages
 - Investigate differential-temperature operation
- ▶ Test as part of integrated fuel processor with steam reformer, water-gas-shift reactors and heat exchangers
 - Evaluate fast startup, rapid transient potential
 - Evaluate thermal recuperation of PROX heat

Reformate Desulfurization Using Microchannel Devices

- ▶ Concept: microchannel absorbers can provide compact units for H_2S removal from reformate
 - ZnO absorption:
 - Fast uptake kinetics at $T \geq 400^\circ\text{C}$ but relatively high equilibrium H_2S concentration in high steam environments
 - Slower kinetics at $T \leq 300^\circ\text{C}$ but lower equilibrium H_2S concentration
 - Differential temperature microchannel absorber can provide more effective H_2S removal by operating over temperature range $300\text{-}400^\circ\text{C}$
- ▶ Challenge: absorber bed capacity in microchannel configuration
- ▶ Approach and status
 - Carry out initial studies (underway) to quantify ZnO uptake kinetics vs. T
 - Calculate optimal temperature profile for differential temperature absorber
 - Construct microchannel unit and obtain experimental performance data under differential temperature conditions
 - Compare results with isothermal operation

Balance-of-Plant

Partial Condenser / Phase Separator

- ▶ Objective: Develop compact microchannel heat exchange technology for the recovery and recycle of water in fuel processor / fuel cell systems.
- ▶ Designed for water recovery from PEM fuel cell cathode effluent
- ▶ Condenses and separates water
- ▶ Aluminum for light weight
- ▶ Air-cooled
- ▶ Cross-flow for low coolant-air pressure drop
- ▶ 1.5-kWe-scale cathode condenser
 - Air coolant - 30 °C
 - Air pressure drop - 2.2 in. H₂O
 - Weight - 260 g
 - Volume - 170 mL
 - Est. Fan Power - 14 W full-scale




3 condensing channels (left to right)
4 cooling channels with fins




Vapor-Liquid Separator

Measured versus Predicted Performance



- 32 std Liter/min air flow
- 48 std Liter/min air flow
- Average model prediction



CONCLUSIONS

- Actual performance exceeds predicted performance.
- 2000 W_t/kg specific power at 74% water recovery.
- Water separation efficiency 90-100%.
- Coolant side pressure drop about 2X design ~ 4 in. H₂O.

Interactions

▶ Catalyst Development

- Sud-Chemie, Inc. – WGS, PROX, Desulfurization
- Engelhard - PROX

▶ Technology Transfer

- Interest expressed by SOFCo for a 50-kWe-scale Differential Temperature Water Gas Shift reactor.

▶ Technology Spin-off

- Microchannel Partial Condenser / Phase Separator successfully tested in zero gravity onboard NASA's KC-135 aircraft.
- Microchannel Phase Separator is a candidate technology for NASA's Space Plane for water recovery from cathode of PEM FC power system.

Responses to Comments

- ▶ *“WGS durability may be a significant challenge...” and “Lack of WGS durability data”*
 - Catalyst deactivation has been a challenge, particularly with thermal cycles and restarts, and is under investigation.
 - A single catalyst piece has been on stream for 100 hours with nominal initial deactivation; ~ 10-20%.

- ▶ *“Little of proposed work is related to advancing fundamental understanding, which should be of high importance”*
 - WGS work is pursuing a fundamental understanding, including:
 - Kinetic model development in an engineered form
 - Finite element heat and mass transfer models of reactors for analysis and design
 - Scale-up from single channel to multi-channel reactors to understand the issues associated with scale-up, such as flow maldistribution