Irvine, California



P. A. DeBarber, T. P. Jenkins, E. H. Scott, MetroLaser, Inc., Irvine, CA

DOE Sensors and Controls Annual Meeting Las Vegas, NV, June 11, 2002



# **Outline**

- Motivation
- System Design
- Outline of Theory
- Calibration
- Results from a Flat Flame
- Conclusions & Future Work

MetroLaser
Irvine, California

## **Motivation**

- Improved energy efficiency is needed for Industries of the Future (IOF) to stay globally competitive
- Future emissions regulations will require closer monitoring of industrial combustors
- In situ sensors for active control are scarce
- Accurate, robust, and inexpensive sensors are needed for industrial combustion monitoring

MetroLaser

Irvine, California

# **Objective**


To build and test a Tunable Diode Laser Absorption Spectroscopy (TDLAS) system to measure real-time concentrations and temperatures non-intrusively in industrial burners

# Scope

- Design and build a robust diode laser system to withstand the harsh environments of industrial applications
- Calibrate and test the system in a laboratory
  - Integrate the system into an industrial burner
  - Test the system in real-world conditions


Irvine, California

# TDLAS System for Monitoring Temperature and H<sub>2</sub>O in Industrial Burners





# Theory of Mole Fraction $(X_i)$ Measurements: Scanned Wavelength Absorption Spectroscopy



Beer-Lambert relation:

$$\frac{I_{\nu}}{I_0} = \exp(-k_{\nu}L)$$

For line *j* of species *i*:

$$k_{v} = PX_{i}S_{j}\phi_{j}$$

Where:
$$S_{j} = S_{j}(T)$$
$$\phi_{j} = \phi_{j}(v)$$

$$I_{v}$$


$$k_{v} = -\frac{1}{L} \ln \left( \frac{I_{v}}{I_{0}} \right)$$

Measured  $k_{v,peak}$  yields  $X_i$  from:

$$X_{i} = \frac{k_{v,peak}}{PS_{j}\phi_{j}}$$

Irvine, California

# Theory of Temperature (*T*) Measurements: Two-line absorption ratio technique



Ratio of peak absorbances:

$$R_{peak} = \frac{\left(k_{v,1}\right)_{peak}}{\left(k_{v,2}\right)_{peak}} = \frac{S_1(T_0)\phi_1}{S_2(T_0)\phi_2} \exp\left[-\frac{hc}{k}\left(E_1" - E_2"\right)\left(\frac{1}{T} - \frac{1}{T_0}\right)\right]$$

Measured  $R_{peak}$  is sensitive primarily to T only.




Irvine, California



#### Ideal:


\*



#### Noise sources:

- •Flame emission
- •Laser amplitude noise
- Detector noise
- Amplifier noise

#### Real:




### Noise reduction techniques:

- Balanced detection
- Frequency shifting with lock-in detection

Irvine, California

## Noise Reduction by Modulation & Phase Detection: Shifting in Frequency Space




#### Lock-in detection method:

- $\bullet$  Signal is frequency-shifted by modulating laser at  $f_{mod}$
- Modulated signal is detected by a phase-sensitive method
- ullet Noise is not modulated, thus is greatly reduced at  $f_{mod}$

Irvine, California


# **Example of Lock-in Detection**



Irvine, California

# **Example of Lock-in Detection**


#### Signal A is Modulated to get Signal b



MetroLaser
Irvine, Califòrnia

## **Example of Lock-in Detection**


## Signal b is multiplied by $\textit{cos}(\omega_{\text{dm}}t)$ to get signal c



Irvine, California

# **Example of Lock-in Detection**


### Signal c filtered = A/2






# Wavelength Modulation Spectroscopy

#### Lock-in detection applied to an absorption scan



#### Scan Waveform:

- High-freq. Modulation enables lock-in detection for noise reduction
- Current ramp produces laser wavelength scan




#### Waveform with absorbance:

- Absorption modifies waveform
- Lock-in signal is sensitive to absorption




# Wavelength Modulation Spectroscopy

#### Lock-in detection applied to an absorption scan



#### 1f Waveform:

- $\omega_{dm} = \omega_{mod}$
- Waveform resembles 1<sup>st</sup> derivative of lineshape




#### 2f Waveform:

- $\omega_{dm} = 2\omega_{mod}$
- Waveform resembles 2<sup>nd</sup> derivative of lineshape
- •2f signal = 0 in the wings

\*

# Calibration of TDLAS System



Irvine, California

## Failure of Thermocouple at High Temperature




- S-type thermocouple fails during use at T > 2000 K
- Thermocouple life is significantly reduced for T > 1800 K

Irvine, California




### **Detail of Interface Hardware**




- Transmitter and detector mounted rigidly using pipe fittings
- Single detector simplifies the system

## Characterization of Premixed Flat Flame



- Corrected thermocouple measurements in good agreement with thermochemical equilibrium calculations.
- Temperatures can be varied over 300 K while flame remains stable.


## Example Scan in a CH<sub>4</sub>/air Flat Flame



- Scanning range covers entire line
- Good agreement with simulation based on HITEMP database


Irvine, California

# Signal Processing Program






# Calibration of 2f Ratio for Temperature




• Simulated 2*f* ratio anchored by thermocouple data, establishing a calibration

Irvine, California

# H<sub>2</sub>O Profile in 1-D Flame Measured Using TDLAS






- Experimental mole fractions in good agreement with theoretical
- Measured  $X_{\rm H2O}$  decreases with height due to mixing



## TDLAS Temperature Profile in 1-D Flame




- Measurements made near the flame zone where thermocouples fail
- Data rate of 10 Hz surpasses thermocouple system by 20x



Irvine, California


### Raw Data: TDLAS and TC

2<sup>nd</sup> Harmonic of Absorbances X = 10.5 cm, Nozzle Temp = 110, Tip Ox = 3.25, Flow = 5






## **Shells of Constant Absorbance**



Irvine, California


## Calibration

#### 2f calibration for TDLAS



Irvine, California


## Measured Temperature: TDLAS and TC



MetroLaser

Irvine, California

## Measured H<sub>2</sub>O Concentration





## Conclusions

- A TDLAS system has been developed and calibrated for Real-time in situ measurements of T and X<sub>H2O</sub> in industrial applications
- The system enabled measurements in the flame zone where thermocouples failed
- Data rates of 10 Hz were demonstrated, with potential for being greater
- TDLAS sensors may help improve efficiency in and reduce pollution from industrial burners.



## **Future Work**

- Demonstrate measurements of T & X<sub>H2O</sub> in an industrial spray jet flame, and in a low-NO<sub>x</sub> staged-fuel combustor
- Incorporate additional species, including CO<sub>2</sub>, CO,
   NO, etc.
- Develop lower-cost version of current modulation electronics for commercial use



# Acknowledgements

- Gideon Varga, DOE
- Scott Samuelsen's
   Group, University of
   California, Irvine
- Ron Hanson's Group,
   Stanford University